













CIVIC SI - MOTOR MOUNTS INSTALLATION MANUAL

TOOLS REQUIRED

Set of car stands
 M17 socket wrench
 M19 socket wrench
 M17 box wrench

MATERIALS REQUIRED

None

<p>1 When lifting the car always use stands to secure the car.</p>	<p>2 Remove top mount bolts.</p>	<p>3 Remove the top mount.</p>	<p>4 Remove front mount main bolt.</p>
			
<p>5 Remove front mount bracket bolts.</p>	<p>6 Remove coolant hose from support and push it over support bracket.</p>	<p>7 Push the front mount toward the radiator.</p>	<p>8 Twist the front mount to the right.</p>
			
<p>9 Remove the front mount.</p>	<p>10 Remove rear mount bolts.</p>	<p>11 Push the engine toward the front of the car and slide the rear mount down and out.</p>	<p>12 Get the Boomba Motor Mounts ready.</p>
			

13 Insert the rear mount.



14 Line up mounting holes and insert mounting bolts. **Do not tighten bolts yet.**



15 Insert the front mount.



16 Secure the front mount to the engine with three bolts. **Do not tighten bolts yet.**



17 Insert the main bolt. **Tighten all bottom mounting bolts.**



18 Insert coolant hose in its bracket.



19 Insert the top mount.



20 Line up and insert the rear bolt.



21 Line up and insert front bolts. **Tighten all top mounting bolts.**

