

boomba racing

WEIGHTED SHIFT KNOB

1. Out of direct sunlight, screw shift knob knob securely onto shift lever.
2. Use hair dryer or heat gun and heat up all sides of the knob as evenly as possible until hot to the touch.
3. While wearing protective gloves, twist delrin shell **CLOCKWISE** until shift pattern is lined up.
4. Allow shift knob to cool down for 15-20 minutes before driving.

