




boomba racing

'21+ FORD BRONCO 2.3L ECOBOOST BOV ADAPTOR

INSTALLATION GUIDE



Tools Required: E5 External Torx Socket Phillips Screwdriver

- 1) Locate the OEM diverter valve on the charge pipe on the passenger side of the engine bay.
- 2) Unplug the wiring harness and use the E5 socket to remove the 3 screws securing the OEM diverter valve.
- 3) Install the **Boomba BOV adaptor** between the charge pipe & the OEM diverter valve using the philips screwdriver & the provided hardware.
- 4) Reconnect the wiring harness. Enjoy!