

CIVIC X - SHIFT KNOB

TOOLS REQUIRED

Phillips screw driver
Wire cutter
Plastic trim tools
Razor blade
Measuring tape

MATERIALS REQUIRED

None

1	Remove the left center console trim pulling it in the arrows direction.	2	Remove the right center console trim pulling it in the arrows direction.	3	Remove the screw holding the shifter boot.	4	Pull boot assembly up to release the latches.
							
5	Disconnect the electrical connectors located under the boot assembly.	6	Disconnect the electrical connectors located under the boot assembly.	7	Unscrew the shift knob turning it counterclockwise.	8	Prepare the Bomba Racing shift knob.
							
9	Cut the zip tie securing the boot to the stock shift knob.	10	Measure section of the boot 2.25 inches across. Draw the line and cut it off top portion of the boot with the scissors.	11	Insert the Bomba Racing shift knob into the boot and secure it with provided zip tie.	12	Thread the Bomba Racing shift knob onto the shifter shaft.
							

13	Reconnect the electrical harness connectors.	14	Reconnect the electrical harness connectors.	15	Secure the boot assembly to the center console.	16	Install the center console trims. Line up the shift pattern insert and press it into the shift knob.
							