

FORD FIESTA ST

CATCH CAN STAGE 1

TOOLS REQUIRED

M7 socket
M5, M6 allen wrench
Flat screw driver
Pliers
Box cutter
Heat gun

Work gloves

MATERIALS REQUIRED

1	Remove the engine cover.	2	Disconnect and remove the vacuum lines.	3	Remove the air intake.	4	Two threaded holes will be used for the installation of the catch can.
							
5	Prepare the Catch Can installation kit.	6	Install the Catch Can bracket.	7	Move the Catch Can mounting clamp to the position shown in the picture.	8	Mount Catch Can to the bracket. Adjust Catch Can's vertical position. Tighten the clamp.
							
9	Cut the factory vent line.	10	Oil the inside of the vent lines.	11	Heat the ends of the vent lines with the heat gun and press the fittings. WEAR HEAVY DUTY WORK GLOVES TO PREVENT BURNS.	12	Oil the inside of the supplied vent lines.
							

13	Press the vent lines onto the Catch Can's fittings. Longer hose to "OUT", shorter hose to "IN".	14	Install the air intake.	15	Connect the vent lines and the vacuum hose. Use zip ties to dress up the vent lines.	16	Install the engine cover.
							