

FORD FIESTA ST SHIFTER PLATE

TOOLS REQUIRED

M7 socket wrench
M10 socket wrench
T25 Torx bit
Large flat screw driver

MATERIALS REQUIRED

None

1	Disconnect the MAF sensor.	2	Remove the air filter cover.	3	Remove the air filter.	4	Remove the vent line.
							
5	Loosen the air pipe clamp and remove the air pipe.	6	Snap off the air supply duct from the latch.	7	Remove the air box.	8	Pry off the shifter cable from the shifter arm with the flat head screw drivers.
							
9	Boomba Shifter Plate ready for installation. The extra hole in the bottom plate should be on the same side that the pivot ball during installation.	10	Slide the Boomba Shifter Plate over the shifter arm.	11	Secure the shifter plate to the bottom plate with provided screws. Reconnect the shifter cable.	12	Reinstall the air supply tube, the vent line and the air filter box. Tighten all hose clamps and bolts. Reconnect the MAF sensor.
							