

FORD FOCUS ST CATCH CAN STAGE 1

TOOLS REQUIRED

M7, M8, M13 sockets
M4, M5 allen wrench
Pliers

MATERIALS REQUIRED

1	Remove the engine cover.	2	Disconnect the vacuum line. Remove the air intake.	3	Remove the vent line.	4	Remove two nuts holding the vacuum line bracket.
							
5	Rotate the hose clamp 90 degrees clockwise.	6	Prepare the Catch Can installation kit.	7	Install the Catch Can bracket over the vacuum line bracket and secure it with the nuts.	8	Install the Catch Can clamp.
							
9	Install the Catch Can and tighten the clamp.	10	Cut the vent line and install the fittings.	11	Lube the inside of the provided vent lines and press them over the fittings. Short hose to "IN", long hose to "OUT".	12	Connect the vent lines to the Catch Can.
							

13	Reconnect the vent lines.	14	Dress the vent lines with the zip ties.	15	Install the intake and reconnect the vacuum line.	16	Install the engine cover.
							