BLOW OFF VALVE ADAPTER INSTALLATION

- TOOLS REQUIRED -5mm allen

- STEP #1 -

Raise & secure the vehicle via lift or jackljackstands and remove the undertray.

Poompo

-STEP#2-

Locate factory bypass valve on charge pipe that runs underneath.

Disconnect the wiring harness and unscrew the 3 screws.

-STEP#3-

Install the Boomba Racing BOV adapter in between the factory bypass valve & the charge pipe, using the provided longer screws.

- STEP #4-

Reconnect the wiring harness

- STEP #5 -

Go for a drive and enjoy your new BOV adapter!