

FORD FUSION SPORT BLOW OFF VALVE ADAPTOR

TOOLS REQUIRED

E-5 socket
M5 allen wrench

MATERIALS REQUIRED

None

1	The blow of valve location.	2	Remove electrical connection. Remove bolts.	3	Prepare Boomba Racing Blow off Valve Adaptor	4	Secure BOV to the intake with provided screw. Reconnect electrical harness.
							