

VOLKSWAGEN GTI Mk8

SHIFTER KNOB

TOOLS REQUIRED

Small flat screw driver
Wire cutter
Razor blade

MATERIALS REQUIRED

None

1	Remove the shifter boot.	2	Insert small screw driver into the loop of the locking strap. Move the screw driver sideways to loosen the strap. Pull the shift knob up to remove.	3	Cut the boot off around the factory shift knob bottom edge. Remove the shift knob.	4	Push out the shift pattern insert.
							
5	Insert Boomba Shift Knob through the boot. Secure the boot to the knob with the provided zip tie.	6	Slide the shift knob over the shaft. Tighten the four set screws around perimeter to secure the shift knob to the shaft. Use provided allen wrench.	7	Reinstall the shifter boot.	8	Line up and press in the shift pattern insert.
							