



boomba racing

'19+ FORD RANGER 2.3L ECOBOOST BOV ADAPTER

INSTALLATION GUIDE



Tools Required: 8mm Socket, Phillips Screwdriver

- 1) Locate the OEM diverter valve on the charge pipe on the passenger side of the engine bay.
- 2) Unplug the wiring harness and remove the 3 bolts securing the diverter valve.
- 3) Install the **Boomba BOV adapter** between the charge pipe & the diverter valve using the provided hardware.
- 4) Reconnect the wiring harness. Enjoy!