

# VELOSTER BOV INSTALLATION

## TOOLS REQUIRED

Pliers  
Flat screw driver  
M10 socket wrench  
M8 box wrench

## MATERIALS REQUIRED

None

<b>1</b>	Remove the front bumper's top fasteners.	<b>2</b>	Remove the front bumper's side fasteners.
			<b>4</b> 
<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>
	Remove the BOV return hose. 	Remove the factory valve's screws. 	Disconnect the vacuum line. Remove the factory valve and the return hose. 
<b>9</b>	<b>10</b>	<b>11</b>	<b>12</b>
Prepare Boomba Racing blow off valve. 	Plug the return port with provided plug. 	Connect the return hose to the intake. 	Connect the vacuum with the provided hose extension. Secure the Blow Off Valve to the intercooler with the provided bolts. Reinstall the front bumper. 