

SUBARU WRX '15+ CATCH CAN STAGE 1

TOOLS REQUIRED

M12 sockets
M4, M6 allen wrench
Flat screw driver
Pliers
Plastic tube cutter

MATERIALS REQUIRED

1	Remove the engine cover.	2	Remove the vacuum line clip.
			
5	Prepare the Boomba Racing Catch Can for installation.	6	Remove the intercooler bolts.
			
9	Connect the vacuum line to the vent tube in front of the intake manifold.	10	Connect the vacuum line to the vent tube under the intake manifold.
		11	Connect the vacuum lines to the catch can.
			12
			Install the engine cover.
			